

ORP60-DE replacement ORP probe is compatible with the following pen testers:

- ORP60-Z

**Technical Specs:**

<b>Range</b>	-1000 to 1000 mV	<b>Reference</b>	Ag/AgCl
<b>Housing</b>	Polycarbonate	<b>Temp. sensor</b>	30KΩ thermistor
<b>Junction</b>	Double ceramic	<b>Electrolyte</b>	Gel KCL
<b>Sensor Type</b>	Platinum	<b>Operating temp.</b>	32 to 122°F (0 - 50°C)

**How to replace the probe?**

Screw off the probe ring, unplug the probe, plug in the new replacement probe (pay attention to the probe’s position), and screw on the probe ring.

**Notes**

1. Soak the ORP probe in 222 mV standard ORP solution for 15-30 minutes can improve the sensor’s performance.
2. ORP probes don’t last forever. Every ORP probe will eventually age and fail even if you don’t use it that often. The typical service life of Apera probes is 12-24 months depending on the frequency of usage and how well you keep it clean and properly stored. We recommend replacing your probe every 12-18 months to ensure the best accuracy.



**Limited Warranty**

How Long Does the Coverage Last?

Apera Instruments® (Apera) warrants the ORP60-DE Replacement Probe (Product) for a period of 6 months from date of purchase by original purchaser or consumer. Proof of purchase is required for the warranty to be effective (store sales receipt for Product showing model number, payment and date of purchase). This warranty is non-transferable and terminates if the original purchaser/consumer sells or transfers the Product a third party.