

301DJ-C Electrode



Main Features

- Ideal for long-term measurements in turbid water (wastewater, swimming pools, spas, environmental monitoring)
- Double junction structure prevents clogging and contamination of the electrode
- Cable length: 1 meter
- Compatible with all ORP meters with a BNC connector

Technical Parameters

Measuring range	±2000mV	Electrolyte	Gel KCl
Sensor	(Ø 0,8×3) mm platinum pin	Reference system	Ag/AgCl
Junction	Double ceramic	Electrode dimensions	(Ø 12×120)mm
Body material	PC (polycarbonate)	Connector	BNC
Recommended operating temperature	(0-80)°C	Cable	Ø 3×1 m